

## FRONT NO.3 CROSSMEMBER (CUT-H) REPLACEMENT

- 1. REMOVE RADIATOR SUPPORT (See page BP-1)
- 2. REMOVE FRONT CROSSMEMBER (See page BP-3)
- 3. REMOVE FRONT FENDER APRON (See page BP-8)
- 4. REMOVE FRONT SIDE MEMBER (See page BP-15)
- 5. REMOVE FRONT NO.3 CROSSMEMBER
- (a) Cut and join the parts at the location as shown below.



## 6. INSTALL FRONT NO.3 CROSSMEMBER

(a) Cut the new parts for the front side member to dash crossmember at the location as shown below.



- 7. INSTALL FRONT SIDE MEMBER (See page BP-15)
- 8. INSTALL FRONT FENDER APRON (See page BP-8)
- 9. INSTALL FRONT CROSSMEMBER (See page BP-3)
- 10. INSTALL RADIATOR SUPPORT (See page BP-1)
- 11. MEASURING THE ENGINE COMPARTMENT DIMENSIONS (See page BP-88)
- 12. MEASURING THE UNDERBODY DIMENSIONS (See page BP-88)
- 13. APPLYING SEALER TO THE ENGINE COMPARTMENT (See page PC-1)
- 14. APPLYING SEALER TO THE INSIDE OF THE VEHICLE (See page PC-1)
- 15. APPLYING UNDER COATING (See page PC-7)
- 16. INSTALL SILENCER SHEET (See page PC-11)
- 17. APPLYING ANTI-RUST AGENT
- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.