## **EQUIPMENT**

PP0S9-01

Feeler gauge	Check major clearance.
Vernier calipers	Check length of 2nd coast brake piston rod.
Dial indicator or dial indicator with magnetic base	Check piston stroke and play of the output shaft.
Dial indicator	Check inside diameter of major bushing.
Straight edge	Check side clearance of oil pump.
Torque wrench	
Cylinder gauge	Check inside diameter of the transmission case rear bushing.