

# AIR CONDITIONING SYSTEM PRECAUTION

550BP-0



- 1. DO NOT HANDLE REFRIGERANT IN AN ENCLOSED AREA OR NEAR NAKED FLAME
- 2. ALWAYS WEAR EYE PROTECTION



### 3. BE CAREFUL NOT TO GET LIQUID REFRIGERANT IN YOUR EYES OR ON YOUR SKIN


If liquid refrigerant gets in your eyes or on your skin:

(a) Wash the area with lots of cool water.

### **CAUTION:**

Do not rub your eyes or skin.

- (b) Apply clean petroleum jelly to the skin.
- (c) Go immediately to a physician or hospital for professional treatment.
- 4. NEVER HEAT THE CONTAINER OR EXPOSE IT TO NAKED FLAME
- 5. BE CAREFUL NOT TO DROP THE CONTAINER OR APPLY PHYSICAL SHOCKS TO IT



# 6. DO NOT OPERATE THE COMPRESSOR WITHOUT ENOUGH REFRIGERANT IN THE REFRIGERANT SYSTEM

If there is not enough refrigerant in the refrigerant system, oil lubrication will be insufficient and compressor burnout may occur. Necessary care should be taken to avoid this.

# 7. DO NOT OPEN HIGH PRESSURE MANIFOLD VALVE WHILE COMPRESSOR IS OPERATING

If the high pressure valves are opened, refrigerant flows in the reverse direction and could cause the charging cylinder to rupture. Open and close only the low pressure valve.

## 8. BE CAREFUL NOT TO OVERCHARGE SYSTEM WITH REFRIGERANT

If refrigerant is overcharged, it causes problems such as insufficient cooling, poor fuel economy, engine overheating etc.

# 9. DO NO DERATE ENGINE AND COMPRESSOR WITH NO REFRIGERANT

### **CAUTION:**

Doing[so[may[damage]the[inside[of[the[compressor[because]the[compressor[parts[always[move[regardless[of whether[the[A/C[system[is]turned[on[or[off.

### 10. SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

The LEXUS LS430 [sequipped with an SRS [Supplemental Restraint system) such as the driver, front passenger, side, curtain shield air pags etc. Failure to carry out service operation in the correct sequence could cause the SRS to unexpectedly deploy during servicing, possibly leading to serious accident. Before servicing [including temoval or installation of parts, inspection or replacement), be sure to read the precautionary notices on page 60-1.

# 11 PRECAUTION FOR DISCONNECTING THE BATTERY CABLE

### **NOTICE:**

When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal screen nected.

System Name	see page
Power window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20