
SYSTEM DIAGRAM

610IU-01



DESCRIPTION

When the ignition switch is turned ON and the passenger or driver side seat belt is not fastened, the seat belt warning system repeatedly flashes the seat belt warning lamp. The system determines if the seat belt is fastened by checking if the seat belt buckle switch is ON (seat belt fastened) or OFF (seat belt unfastened).