TROUBLESHOOTING

DESCRIPTION

BE21D-02

 $\label{thm:local_problem} \mbox{Description of Each System Mentioned in the DI Section Related to Gateway System.}$

HINT:

Master control means that the Control ECU becomes a master and controls each electric system.

The sub control system transmits to the Master Control ECU the signals of the switches that are connected to the ECU. It also operates the motor by receiving the command of the Master Control ECU.

CRUISE CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Engine and ECT ECU Distance ECU	Cruise control system	-

STEERING LOCK SYSTEM (w/ Smart key system)

Control ECU	Master control system	Sub control system
Steering lock ECU Engine and ECT ECU	Steering lock system Engine immobiliser system	Smart key system Light auto turn off system Key remainder warning system Door lock system (Key confinement prevention function) Power tilt and power telescopic steering column

ENGINE IMMOBILISER SYSTEM (w/o Smart key system)

Control ECU	Master control system	Sub control system
Transponder key ECU Engine and ECT ECU	Engine immobiliser system	 Light auto turn off system Key remainder warning system Door lock system (Key confinement prevention function) Power tilt and power telescopic steering column

CONBINATION METER SYSTEM

Control ECU	Master control system	Sub control system
Combination meter ECU	Combination meter system	Rader cruise control display
	Fuel gauge system	Headlight beam level control system
	Buzzer (Key remainder warning, Seat belt	Door lock system (Automatically locked by ve-
	warning, Light on-warning)	hicle speed)
	Multi information display	Smart key system
		Automatic light control system
		LEXUS park assist system
		Seat position memory system
		Wiper system

SLIDING ROOF SYSTEM

Control ECU	Master control system	Sub control system
Sliding roof control ECU	Sliding roof system	Wireless door lock control system
		Combination meter (Buzzer)

DRIVER SIDE J/B CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Control ECU Driver side J/B control ECU	Master control system Automatic light control system Light auto turn off system Illumination system (Switch illuminations, Combination meter illumination) Driver side buckle illumination Illuminated entry system Rheostat light control system Daytime running light system Back-up light system License plate light Rear fog light system Stop light system Taillight system Turn signal and hazard warning system Front fog light system Front clearance light	Sub control system Luggage compartment door opener system Theft deterrent system Combination meter (Pad wear indicator light) Seat belt warning system Remote control mirror system Retract mirror system Electric tension reducer system Power shoulder belt anchorage system Fuel lid opener system Headlight cleaner system Wiper system Smart key system
	Headlight system Side marker light	

PASSENGER SIDE J/B CONTROL SYSTEM

Control ECU	Master control system	Sub control system
	Illumination and interior light system (Vanity light, Interior light, Front personal light, Step light, Outer foot light (in outer mirror) Ignition key illumination, Door courtesy light) Passenger side buckle illumination Illuminated entry system Wiper and washer system	Headlight beam level control system Combination meter (Pad wear indicator light) LEXUS navigation system Seat belt warning system Power shoulder belt anchorage system Rear sunshade system

LUGGAGE ROOM J/B CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Luggage room J/B control ECU	Rear seat buckle illumination	Automatic light control system
	Luggage compartment light	Smart key system
	Luggage compartment door opener system	Theft deterrent system
	Luggage compartment door closer system	Wireless door lock control system
	Rear sunshade system	Combination meter (Fuel sender gauge)
	Fuel lid opener system	Rear passenger's power seat system
	Back-up light system	Rear air conditioning system
	License plate light	Rear sunshade system
	Rear fog light system	
	Stop light system	
	Taillight system	
	Turn signal and hazard warning system	

FRONT LIGHT CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Front light control ECU	 Front fog light system Front clearance light Headlight system Side marker light Horn system 	Combination meter (Washer fluid level warning light) Light auto turn off system Automatic light control system

DRIVER DOOR CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Driver door control ECU	Power window control system	Light auto turn off system
	Remote control mirror system	Door courtesy light
	Retract mirror system	Illuminated entry system
	Door closer system	Combination meter (Door warning light)
	Automatic glare-resistant EC mirror system	Theft deterrent system
	Mirror heater system	Wireless door lock control system
	Power shoulder belt anchorage system	Outer foot light (in outer mirror)
		Door lock system
		Door lock system (Key confinement prevention
		function)
		Double locking system
		Smart key system
		Key remainder warning system
		Seat position memory system

PASSENGER DOOR CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Passenger door control ECU	Door closer system	Door courtesy light
	·	Illuminated entry system
		Outer foot light (in outer mirror)
		Door lock system
		Door lock system (Key confinement prevention
		function)
		Double locking system
		Power window control system
		Smart key system
		Key remainder warning system (Key unlock
		warning signal)
		Automatic glare-resistant EC mirror system
		Remoto control mirror system
		Retract mirror system
		Mirror heater system
		Wireless door lock control system
		Power shoulder belt anchorage system
		Combination meter (Door warning light)
		Theft deterrent system

REAR LEFT DOOR CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Rear left door control ECU	Door closer system	Door courtesy light
		Illuminated entry system
		Door lock system
		Door lock system (Key confinement prevention
		function)
		Double locking system
		Power window control system
		Smart key system
		Key remainder warning system (Key unlock
		warning signal)
		Rear passenger's power seat system
		Combination meter (Door warning light)
		Wireless door lock control system

REAR RIGHT DOOR CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Rear right door control ECU	Door closer system	Door courtesy light
		Illuminated entry system
		Door lock system
		Door lock system (Key confinement prevention
		function)
		Double locking system
		Power window control system
		Smart key system
		Key remainder warning system (Key unlock
		warning signal)
		Rear passenger's power seat system
		Combination meter (Door warning light)
		Wireless door lock control system

THEFT DETERRENT SYSTEM

Control ECU	Master control system	Sub control system
Theft deterrent ECU	 Theft deterrent system Door lock system Double locking system Smart key system Wireless door lock control system 	 Power window control system (Jam protection system) Steering lock system Retract mirror control system Light auto turn off system Illuminated entry system Luggage door opener system Fuel lid opener system

POWER SEAT CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Power seat control ECU (Seat position	Driver's power seat system	
ECU)	Seat position memory	-

REAR RIGHT SEAT CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Rear right seat control ECU	Rear passenger's (RH) power seat system	
Vibration seat ECU	Vibration seat system	-

REAR LEFT SEAT CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Rear left seat control ECU	Rear passenger's (LH) power seat system	
Vibration seat ECU	Vibration seat system	-

COMBINATION SWITCH CONTROL SYSTEM

Control ECU	Master control system	Sub control system
Control ECU Combination switch	Master control system -	Sub control system Front fog light system Headlight system Taillight system Turn signal system Wiper and washer system Tilt and telescopic steering system
		Auto wiper system Automatic light control system LEXUS park assist system

STEERING PAD SWITCH SYSTEM

Control ECU	Master control system	Sub control system
Steering pad switch		Multi information display LEXUS navigation system
	_	Cellular mobile telephone
		Radio and player system

LEXUS PARK ASSIST SYSTEM

Control ECU	Master control system	Sub control system
Clearance sonar ECU	LEXUS park assist system	-

RAIN SENSOR SYSTEM

Control ECU	Master control system	Sub control system
Rain sensor	Automatic wiper system	LEXUS park assist system

REAR SEAT SWITCH SYSTEM

Control ECU	Master control system	Sub control system
Rear seat switch	Seat heater system (Rear)	Rear air conditioning system
		Rear passenger's power seat system

GATEWAY SYSTEM

Control ECU	Master control system	Sub control system
Gateway ECU	Multiplex communication (Gateway) system	_

LEXUS NAVIGATION SYSTEM

Control ECU	Master control system	Sub control system
Navigation ECU	LEXUS navigation system	LEXUS park assist system
Multi display (ECU)	Cellular mobile telephone	Fuel sender gauge
		Automatic light control system
		A/C system

SRS SYSTEM

Control ECU	Master control system	Sub control system
Airbag sensor assembly	SRS system	Fuel cut system Passenger seat belt warning system

ENGINE SYSTEM

Control ECU	Master control system	Sub control system
Engine and ECT ECU	Engine control system Automatic transmission control system Fuel cut system when impact sensing	Air conditioning system Fuel gauge system Remote control mirror system Seat position memory system Wiper system
		Combination meter (Engine oil level warning) Combination meter (Oil pressure warning) Rear air conditioning system Auto wiper system

ABS SYSTEM

Control ECU	Master control system	Sub control system
	ABS system VSC system Brake assist system Traction control system Electric brake force distribution system Progressive power steering system	Combination meter (Parking brake warning) Combination meter (Brake fluid level warning)

A/C SYSTEM

Control ECU	Master control system	Sub control system
A/C ECU	Air conditioning system	Mirror heater system
	Clock	
	Rear air conditioning system	
	Rear window defogger system	

TILT AND TELESCOPIC STEERING SYSTEM

Control ECU	Master control system	Sub control system
Tilt and telescopic steering ECU	Tilt and telescopic steering system	Seat position memory system











