
F11689


BODY PANEL SEALING AREAS


HINT:


- Prior to applying body sealer, clean the area with a rag soaked in grease, wax and silicone remover.
- 1) 2) If weld-through primer was used, first wipe off any excess and coat with anti-corrosion primer before applying
- 3) Wipe off excess body sealer with a rag soaked in a grease, wax and silicone remover.
- *4*) If body sealer is damaged by peeling, cracks, etc., be sure to repair as necessary.

*********** Flat Finishing No Flat Finishing **ENGINE COMPARTMENT**









11 of 13

