
## **BODY LOWER BACK PANEL (ASSY)**

## **REPLACEMENT**


1. REMOVE BODY LOWER BACK PANEL



## 2. INSTALL BODY LOWER BACK PANEL

HINT:

Inspect the fitting of the luggage compartment door and rear combination light, etc., before welding, since this attects the appearance of the finish.



- 3. MEASURING THE OPENING PORTION DIMENSIONS (See page BP-88)
- 4. APPLYING SEALER TO THE REAR LUGGAGE COMPARTMENT (See page PC-1)
- 5. APPLYING UNDER COATING (See page PC-7)
- 6. APPLYING ANTI-RUST AGENT
- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.