Engine Room No.1 R/B (See Page 81)

	Fuse	System	Page
7.5A	A/C IG	Automatic Air Conditioner (Front) [LHD]	878
7.07	7,010	Automatic Air Conditioner (Front) [RHD]	890
7.5A	EFI NO.2	Engine Control (LHD)	212
7.57	LIT NO.2	Engine Control (RHD)	224
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Back-Up Light (LHD)	392
		Back-Up Light (RHD)	394
		Charging (LHD)	204
		Charging (RHD)	208
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
7.5A	FR IG	Headlight Cleaner (LHD)	826
1.5/		Headlight Cleaner (RHD)	828
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
		Radiator Fan (LHD)	874
		Radiator Fan (RHD)	876
		Rear Window Defogger (LHD)	830
		Rear Window Defogger (RHD)	832
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
7.5A	IGN	ECT and A/T Indicator (LHD)	634
7.5A	IGN	ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
7.5A	STA	Engine Control (LHD)	212
7.5A		Engine Control (RHD)	224
		Starting and Ignition (LHD)	196
		Starting and Ignition (RHD)	200
		Automatic Light Control (LHD)	444
7 5 ^	TAIL	Automatic Light Control (RHD)	448
7.5A	TAIL	Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Smart Key System (LHD)	464
7.5A	TAIL	Smart Key System (RHD)	476
7.5A	IAIL	Taillight (LHD)	372
		Taillight (RHD)	378
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
10A	ETCS	ECT and A/T Indicator (LHD)	634
10/1		ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
ı		Engine Control (RHD)	224
		Horn (LHD)	814
		Horn (RHD)	816
		Multiplex Communication System (J/B ECU) [LHD]	264
10A	HORN	Multiplex Communication System (J/B ECU) [RHD]	294
10/1	TIOTIN	Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Engine Control (LHD)	212
10A	INJ	Engine Control (RHD)	224
1071		Starting and Ignition (LHD)	196
		Starting and Ignition (RHD)	200
		Front Fog Light (LHD)	364
15A	FR FOG	Front Fog Light (RHD)	368
15/1	111100	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Headlight (LHD)	356
15A	H-LP L LWR	Headlight (RHD)	360
10/1		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Headlight (LHD)	356
15A	H-LP R LWR	Headlight (RHD)	360
10/1		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Headlight (LHD)	356
20A	H-LP HI	Headlight (RHD)	360
20A	Lu-ra ui	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Multiplex Communication System (J/B ECU) [LHD]	264
20A	WASHER	Multiplex Communication System (J/B ECU) [RHD]	294
20A	WASHEN	Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
30A	EFI NO.1	ECT and A/T Indicator (LHD)	634
30A	EFI NO.1	ECT and A/T Indicator (RHD)	642
		Engine Control (LHD)	212
		Engine Control (RHD)	224
30A	H-LP. CLN	Headlight Cleaner (LHD)	826
307	TI-LI . OLIN	Headlight Cleaner (RHD)	828
		Multiplex Communication System (J/B ECU) [LHD]	264
30A	WIP	Multiplex Communication System (J/B ECU) [RHD]	294
	VVIF	Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628

Engine Room No.3 R/B (See Page 83)

Fuse		System	Page
7.5.4	ABS 3	VSC and PPS (LHD)	664
7.5A	ADS 3	VSC and PPS (RHD)	672

Fusible Link Block (See Page 84, 85)

	Fuse	System	Page
5A	ALT-S	Charging (LHD)	204
	ALI-0	Charging (RHD)	208
		Engine Control (LHD)	212
30A	AM 2	Engine Control (RHD)	224
JOA	AIVI Z	Starting and Ignition (LHD)	196
		Starting and Ignition (RHD)	200
40A	ABS 1	VSC and PPS (LHD)	664
40A	ABS I	VSC and PPS (RHD)	672
40A	ABS 2	VSC and PPS (LHD)	664
404		VSC and PPS (RHD)	672
40A	AIR SUS	Electronic Modulated Air Suspension (LHD)	694
40/		Electronic Modulated Air Suspension (RHD)	704
40A	DEFOG	Rear Window Defogger (LHD)	830
40/		Rear Window Defogger (RHD)	832
50A	FAN	Radiator Fan (LHD)	874
307		Radiator Fan (RHD)	876
50A	HEATER	Automatic Air Conditioner (Front) [LHD]	878
1307		Automatic Air Conditioner (Front) [RHD]	890
50A	LUG J/B	Automatic Light Control (LHD)	444
307	LOG 0/D	Automatic Light Control (RHD)	448

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Back-Up Light (LHD)	392
		Back-Up Light (RHD)	394
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Rear Air Conditioner (LHD)	902
50A	LUG J/B	Rear Air Conditioner (RHD)	908
JUA	LOG WB	Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
80A	FAN	Radiator Fan (LHD)	874
OUA	I AIN	Radiator Fan (RHD)	876
		Charging (LHD)	204
140A	ALT	Charging (RHD)	208
140A		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294

Driver Side J/B (See Page 86, 98)

	Fuse	System	Page
		Multiplex Communication System (J/B ECU) [LHD]	264
5A	D B/ANC	Multiplex Communication System (J/B ECU) [RHD]	294
54	D B/AINC	Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
	STOP	ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
5A		Engine Control (LHD)	212
3^		Engine Control (RHD)	224
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
		Shift Lock (LHD)	722
		Shift Lock (RHD)	724

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Stop Light (LHD)	384
5A	STOP	Stop Light (RHD)	388
SA	3101	VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Automatic Air Conditioner (Front) [LHD]	878
7.5A	A/C	Automatic Air Conditioner (Front) [RHD]	890
7.5/	7,0	Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
7.5A	ABS-IG	VSC and PPS (LHD)	664
7.56	ADO-IG	VSC and PPS (RHD)	672
7.5A	AM1	Multiplex Communication System (J/B ECU) [LHD]	264
7.5/	Alvii	Multiplex Communication System (J/B ECU) [RHD]	294
		Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Multiplex Communication System (Communication Bus) [LHD]	252
		Multiplex Communication System (Communication Bus) [RHD]	258
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Window (LHD)	542
	D-ACC	Power Window (RHD)	550
7.5A		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Shift Lock (LHD)	722
		Shift Lock (RHD)	724
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Charging (LHD)	204
		Charging (RHD)	208
		Combination Meter (LHD) Combination Meter (RHD)	862 868
			650
7.5A	GAUGE	Cruise Control (LHD) Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T indicator (EHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (EHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Headlight Beam Level Control (LHD)	714
		Headlight Beam Level Control (RHD)	718
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Key Reminder and Seat Belt Warning (LHD)	578
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
l		Multiplex Communication System (J/B ECU) [LHD]	264
7.5A	GAUGE	Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Seat Belt Warning (RHD)	582
		Shift Lock (LHD)	722
		Shift Lock (RHD)	724
		SRS (LHD)	679
		SRS (RHD)	687
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
7.5A	MPX-IG	Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Illumination (LHD)	412
		Illumination (RHD)	420
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Communication Bus) [LHD]	252
		Multiplex Communication System (Communication Bus) [RHD]	258
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Power Seat (Driver's Seat) [LHD]	746
		Power Seat (Driver's Seat) [RHD]	750
	MDV IO	Power Shoulder Belt Anchorage (LHD)	586
l		Power Shoulder Belt Anchorage (RHD)	592
7.5A	MPX-IG	Power Tilt and Power Telescopic (LHD)	738
		Power Tilt and Power Telescopic (RHD)	742
		Power Window (LHD)	542
		Power Window (RHD)	550
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		SRS (LHD)	679
		SRS (RHD)	687
		Taillight (LHD)	372
		Taillight (RHD)	378
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Turn Signal and Hazard Warning Light (LHD)	404
		Turn Signal and Hazard Warning Light (RHD)	408
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
7.5A	MPX-IG	Wireless Door Lock Control (LHD w/o Smart Key System)	504
7.5	IVII X-IG	Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
7.5A	OBD	Electronic Modulated Air Suspension (LHD)	694
7.5A	OBD	Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
7	DANIEL	Illumination (LHD)	412
7.5A	PANEL	Illumination (RHD)	420
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Horn (LHD)	814
		Horn (RHD)	816
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
7.5A	SECURITY	Multiplex Communication System (J/B ECU) [LHD]	264
7.57	SECURITY	Multiplex Communication System (J/B ECU) [RHD]	294
		Power Window (LHD)	542
		Power Window (RHD)	550
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Cellular Mobile Telephone (RHD)	838
7.5A	TEL	LEXUS Navigation System (RHD)	846
		Radio and Player (RHD)	856
10A	D RR-IG	Vibration Seat (LHD)	798
107		Vibration Seat (RHD)	802
15A	D S/HTR	Climate Control Seat (LHD)	778
10/1	0,11111	Climate Control Seat (RHD)	782

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
15A	D S/HTR	Seat Heater (Front) [LHD]	786
ISA	D 3/IIIN	Seat Heater (Front) [RHD]	788
15A	D-CIG	Cigarette Lighter and Power Outlet (LHD)	806
134	D-GIG	Cigarette Lighter and Power Outlet (RHD)	808
15A	POWER OUTLET	Cigarette Lighter and Power Outlet (LHD)	806
	TOWER OUTEET	Cigarette Lighter and Power Outlet (RHD)	808
20A	AIRSUS	Electronic Modulated Air Suspension (LHD)	694
207	All 1000	Electronic Modulated Air Suspension (RHD)	704
20A	TI & TE	Power Tilt and Power Telephone (LHD)	738
204	ΠαιΕ	Power Tilt and Power Telephone (RHD)	742
30A	AMP	Radio and Player (RHD)	856
30A	D P/SEAT	Power Seat (Driver's Seat) [LHD]	746
JOA	D P/SEAT	Power Seat (Driver's Seat) [RHD]	750

Passenger Side J/B (See Page 92, 104)

	Fuse	System	Page
5A	H-LP LVL	Headlight Beam Level Control (LHD)	714
JA	II-LF LVL	Headlight Beam Level Control (RHD)	718
		Multiplex Communication System (J/B ECU) [LHD]	264
5A	P B/ANC	Multiplex Communication System (J/B ECU) [RHD]	294
5 /1	I B/ANC	Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
7.5A	CRT	LEXUS Navigation System (LHD)	842
7.5A	ONI	LEXUS Navigation System (RHD)	846
		Engine Immobiliser and Steering Lock System (LHD w/ Smart Key System)	236
	IG2	Engine Immobiliser and Steering Lock System (RHD w/ Smart Key System)	240
7.5A		Engine Immobiliser System (LHD w/o Smart Key System)	244
		Engine Immobiliser System (RHD w/o Smart Key System)	248
		SRS (LHD)	679
		SRS (RHD)	687
	MPX-B1	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Engine Immobiliser and Steering Lock System (LHD w/ Smart Key System)	236
		Engine Immobiliser and Steering Lock System (RHD w/ Smart Key System)	240
7.5A		Engine Immobiliser System (LHD w/o Smart Key System)	244
		Engine Immobiliser System (RHD w/o Smart Key System)	248
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Seat (Driver's Seat) [LHD]	746

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Power Seat (Driver's Seat) [RHD]	750
		Power Seat (Rear Passenger's Seat) [LHD]	762
		Power Seat (Rear Passenger's Seat) [RHD]	770
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Power Window (LHD)	542
		Power Window (RHD)	550
		Remote Control Mirror (LHD)	598
7.5A	MPX-B1	Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Vibration Seat (LHD)	798
		Vibration Seat (RHD)	802
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Cellular Mobile Telephone (LHD)	834
		Charging (LHD)	204
		Charging (RHD)	208
		Combination Meter (LHD)	862
		Combination Meter (RHD)	868
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
		Electronic Modulated Air Suspension (RHD)	704
7.5A	MPX-B2	Engine Control (LHD)	212
7.5	IVII X-D2	Engine Control (RHD)	212
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD) Headlight (RHD)	356
			360 714
		Headlight Beam Level Control (LHD)	
		Headlight Beam Level Control (RHD)	718
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Key Reminder and Seat Belt Warning (LHD)	578
		LEXUS Navigation System (LHD)	842

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		LEXUS Navigation System (RHD)	846
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (Communication Bus) [LHD]	252
		Multiplex Communication System (Communication Bus) [RHD]	258
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
l	MDV Do	Rear Air Conditioner (LHD)	902
7.5A	MPX-B2	Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Seat Belt Warning (RHD)	582
		SRS (LHD)	679
		SRS (RHD)	687
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
		Automatic Light Control (LHD)	444
		Automatic Light Control (RHD)	448
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Fuel Lid Opener (LHD)	574
		Fuel Lid Opener (RHD)	576
		Headlight (LHD)	356
751	MPX-B3	Headlight (RHD)	360
7.5A	INIL V-DO	Illumination (LHD)	412
		Illumination (RHD)	420
		Light Auto Turn Off (LHD)	452
		Light Auto Turn Off (RHD)	458
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Power Tilt and Power Telescopic (LHD)	738
		Power Tilt and Power Telescopic (RHD)	742
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Remote Control Mirror (LHD)	598
7.5A	MPX-B3	Remote Control Mirror (RHD)	606
7.5A	INIPX-B3	Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Taillight (LHD)	372
		Taillight (RHD)	378
		Turn Signal and Hazard Warning Light (LHD)	404
		Turn Signal and Hazard Warning Light (RHD)	408
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
^	D 400	LEXUS Navigation System (LHD)	842
7.5A	P-ACC	LEXUS Navigation System (RHD)	846
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
7.5.4	D 010	Cigarette Lighter and Power Outlet (LHD)	806
7.5A	P-CIG	Cigarette Lighter and Power Outlet (RHD)	808
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Automatic Glare-Resistant EC Mirror (LHD)	822
		Automatic Glare-Resistant EC Mirror (RHD)	824
		Climate Control Seat (LHD)	778
		Climate Control Seat (RHD)	782
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
7.5A	P-IG	Key Reminder and Seat Belt Warning (LHD)	578
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Rear Air Conditioner (LHD)	902

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Rear Air Conditioner (RHD)	908
		Seat Belt Warning (RHD)	582
		Seat Heater (Front) [LHD]	786
		Seat Heater (Front) [RHD]	788
l		Seat Heater (Rear) [LHD w/ Rear Power Seat]	790
7.5A	P-IG	Seat Heater (Rear) [LHD w/o Rear Power Seat]	794
		Seat Heater (Rear) [RHD w/ Rear Power Seat]	792
		Seat Heater (Rear) [RHD w/o Rear Power Seat]	796
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
		Radio and Player (LHD)	850
7.5A	RADIO NO.1	Radio and Player (RHD)	856
7.54	OTD 1 001/	Engine Immobiliser System and Steering Lock System (LHD w/ Smart Key System)	236
7.5A	STR LOCK	Engine Immobiliser System and Steering Lock System (RHD w/ Smart Key System)	240
7.5A	TEL	LEXUS Navigation System (LHD)	842
1.54		Radio and Player (LHD)	850
		Automatic Air Conditioner (Front) [LHD]	878
		Automatic Air Conditioner (Front) [RHD]	890
		Charging (LHD)	204
		Charging (RHD)	208
		Clock (LHD w/o LEXUS Navigation System)	810
		Clock (RHD w/o LEXUS Navigation System)	812
		Combination Meter (LHD)	862
		Combination Meter (RHD)	868
		Cruise Control (LHD)	650
		Cruise Control (RHD)	656
		ECT and A/T Indicator (LHD)	634
		ECT and A/T Indicator (RHD)	642
		Electronic Modulated Air Suspension (LHD)	694
10A	DOME	Electronic Modulated Air Suspension (RHD)	704
		Engine Control (LHD)	212
		Engine Control (RHD)	224
		Front Fog Light (LHD)	364
		Front Fog Light (RHD)	368
		Headlight (LHD)	356
		Headlight (RHD)	360
		Headlight Beam Level Control (LHD)	714
		Headlight Beam Level Control (RHD)	718
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Key Reminder and Seat Belt Warning (LHD)	578

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		LEXUS Navigation System (LHD)	842
		LEXUS Navigation System (RHD)	846
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
		Luggage Compartment Door Opener and Closer (LHD)	566
		Luggage Compartment Door Opener and Closer (RHD)	570
		Moon Roof (LHD)	558
		Moon Roof (RHD)	562
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
10A	DOME	Rear Air Conditioner (RHD)	908
		Rear Fog Light (LHD)	396
		Rear Fog Light (RHD)	400
		Seat Belt Warning (RHD)	582
		SRS (LHD)	679
		SRS (RHD)	687
		Stop Light (LHD)	384
		Stop Light (RHD)	388
		Taillight (LHD)	372
		Taillight (RHD)	378
		VSC and PPS (LHD)	664
		VSC and PPS (RHD)	672
		Wiper and Washer (LHD)	622
		Wiper and Washer (RHD)	628
10A	P RR-IG	Vibration Seat (LHD)	798
IUA	F NN-IG	Vibration Seat (RHD)	802
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
454	HAZ	Smart Key System (LHD)	464
15A		Smart Key System (RHD)	476
		Turn Signal and Hazard Warning Light (LHD)	404
		Turn Signal and Hazard Warning Light (RHD)	408
		Climate Control Seat (LHD)	778
15A	P S/HTR	Seat Heater (Front) [LHD]	786
		Seat Heater (Front) [RHD]	788
	1	Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
25A	D DOOR	Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Power Shoulder Belt Anchorage (LHD)	586
		Power Shoulder Belt Anchorage (RHD)	592
		Power Window (LHD)	542
	D DOOD	Power Window (RHD)	550
25A	D DOOR	Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Mirror Heater (LHD)	614
		Mirror Heater (RHD)	618
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
	D DOOD	Power Shoulder Belt Anchorage (LHD)	586
25A	P DOOR	Power Shoulder Belt Anchorage (RHD)	592
		Power Window (LHD)	542
		Power Window (RHD)	550
		Remote Control Mirror (LHD)	598
		Remote Control Mirror (RHD)	606
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
05.4	C/DOOF	Moon Roof (LHD)	558
25A	S/ROOF	Moon Roof (RHD)	562
30A	AMP	Radio and Player (LHD)	850
30A	P P/SEAT	Power Seat (Front Passenger's Seat) [RHD]	758
30A	P S/HTR	Climate Control Seat (RHD)	782
	1	1	

^{*} These are the page numbers of the first page on which the related system is shown.

Luggage Room J/B (See Page 110)

	Fuse	System	Page
		Automatic Light Control (LHD)	444
7.54		Automatic Light Control (RHD)	448
		Light Auto Turn Off (LHD)	452
	LCE LP	Light Auto Turn Off (RHD)	458
7.5A	LCE LP	Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Taillight (LHD)	372
		Taillight (RHD)	378
		Multiplex Communication System (J/B ECU) [LHD]	264
751	DD A/C	Multiplex Communication System (J/B ECU) [RHD]	294
7.5A	RR A/C	Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Cellular Mobile Telephone (LHD)	834
		Cellular Mobile Telephone (RHD)	838
751	RR ACC	LEXUS Navigation System (LHD)	842
7.5A	INN ACC	LEXUS Navigation System (RHD)	846
		Radio and Player (LHD)	850
		Radio and Player (RHD)	856
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
		Multiplex Communication System (Door ECU) [RHD]	340
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
7.5A	RR ECU-B	Radio and Player (LHD)	850
1.54	Till 200-B	Radio and Player (RHD)	856
		Rear Air Conditioner (LHD)	902
		Rear Air Conditioner (RHD)	908
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	434
		Cellular Mobile Telephone (LHD)	834
		Cellular Mobile Telephone (RHD)	838
		LEXUS Park Assist (Clearance Sonar) [LHD]	726
		LEXUS Park Assist (Clearance Sonar) [RHD]	732
7.5A	RR IG	Multiplex Communication System (Door ECU) [LHD]	324
,	"""	Multiplex Communication System (Door ECU) [RHD]	340
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534

^{*} These are the page numbers of the first page on which the related system is shown.

	Fuse	System	Page
		Fuel Lid Opener (LHD)	574
10A		Fuel Lid Opener (RHD)	576
	FUEL OPN	Luggage Compartment Door Opener and Closer (LHD)	566
IUA	FUEL OFN	Luggage Compartment Door Opener and Closer (RHD)	570
		Multiplex Communication System (J/B ECU) [LHD]	264
		Multiplex Communication System (J/B ECU) [RHD]	294
		Multiplex Communication System (J/B ECU) [LHD]	264
15A	RR S/SHADE	Multiplex Communication System (J/B ECU) [RHD]	294
ISA	INN S/SHADE	Rear Sunshade (LHD)	818
		Rear Sunshade (RHD)	820
		Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
004		Multiplex Communication System (Door ECU) [RHD]	340
20A	RR DOOR LH	Power Window (LHD)	542
		Power Window (RHD)	550
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
		Door Lock Control (LHD w/o Smart Key System)	488
		Door Lock Control (RHD w/o Smart Key System)	496
		Illumination (LHD)	412
		Illumination (RHD)	420
		Interior Light (LHD)	428
		Interior Light (RHD)	436
		Multiplex Communication System (Door ECU) [LHD]	324
20A	RR DOOR RH	Multiplex Communication System (Door ECU) [RHD]	340
20A	RR DOOR RD	Power Window (LHD)	542
		Power Window (RHD)	550
		Smart Key System (LHD)	464
		Smart Key System (RHD)	476
		Theft Deterrent (LHD w/o Smart Key System)	524
		Theft Deterrent (RHD w/o Smart Key System)	534
		Wireless Door Lock Control (LHD w/o Smart Key System)	504
		Wireless Door Lock Control (RHD w/o Smart Key System)	514
20A	RR S/HTR	Seat Heater (Rear) [LHD w/ Rear Power Seat]	790
20A	IUU OUUU	Seat Heater (Rear) [LHD w/o Rear Power Seat]	794

^{*} These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
20A	RR S/HTR	Seat Heater (Rear) [RHD w/ Rear Power Seat]	792
	INN S/HIN	Seat Heater (Rear) [RHD w/o Rear Power Seat]	796
30A	P P/SEAT	Power Seat (Front Passenger's Seat) [LHD]	754
30A	RR SEAT LH	Power Seat (Rear Passenger's Seat) [LHD]	762
	INN SEAT LIT	Power Seat (Rear Passenger's Seat) [RHD]	770
30A	RR SEAT RH	Power Seat (Rear Passenger's Seat) [LHD]	762
	THI SEAT HIT	Power Seat (Rear Passenger's Seat) [RHD]	770

^{*} These are the page numbers of the first page on which the related system is shown.