VOICE ON PHONE CANNOT BE HEARD, TOO QUIET, OR DISTORTED

INSPECTION PROCEDURE

1	CHECK CELLULAR PHONE

(a) Check if the voice on the other side can be heard using a cellular phone.
OK: Voice can be heard.

$$\boxed{\text{NG}} \rangle \boxed{\text{REPLACE THE CELLULAR PHONE}}$$

OK

2	CHECK SETTINGS

(a) Check if the volume is set to the minimum or maximum setting.
HINT:
When the volume is set to the minimum or maximum setting, the sound may be distorted.
(b) Check if the MUTE switch is set to ON.
OK: MUTE switch is not set to ON.

$$\boxed{\text{NG}} \rangle \boxed{\text{SET MUTE SWITCH CORRECTLY}}$$

OK

3	CHECK VOICE

(a) Check if the navigation voice can be heard.
OK: The voice can be heard.

$$\boxed{\text{NG}} \rangle \boxed{\text{GO TO ”VOICE GUIDANCE DOES NOT FUNCTION” (SEE PAGE 05–1823)}}$$

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–1771)