## WIRELESS[DOOR[LOCK[CONTROL[SYSTEM](W/[SMART KEY[SYSTEM])

## **PRECAUTION**

## **NOTICE:**

When disconnecting the megative (-) (battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power Window Control System	05–1 <mark>9</mark> 84
Front Power Seat Control System	05–2280
Back Guide Monitor System	05–1 <u>9</u> 13