
CENTER STOP LAMP ASSY REPLACEMENT

650U2-02

HINT:

Install is in the reverse order of removal.



1. REMOVE CENTER STOP LAMP ASSY

- (a) Slide the center stop lamp assy as shown in the illustration to remove it.
- (b) Disconnect the connector.