
05HDJ-01


NAVIGATION CHECK MODE MICROPHONE CHECK)

HINT:


- The microphone is the cked in the Navigation Check Microphone Check) "mode.
- Illustrations[may[differ[from[]]he[actual[]]yehicle[]]depending[]on[]yehicle[]\$pecifications.
- 1. Start[the[diagnostic[mode[see]page[05-1][80]



2. Select "Navigation Check" from "Diagnosis MENU".



3. Select "Microphone Check" from "Navigation Check".



4. Perform the microphone check by following the directions on the "Microphone Check" screen.