DIAGNOSTIC TROUBLE CODE CHART

05HYC-01

If a malfunction code is displayed during the DTC check, inspect the circuit listed for that code in the table below. Proceed to the page given for that circuit.

DTC No. (See Page)	Detection Item	Trouble Area
B1242 (05–2866)	Wireless door lock tuner circuit malfunction	Wire harness Door control receiver (inner mirror) Door control receiver (luggage) Theft warning ECU (Theft deterrent ECU)