SYSTEM DESCRIPTION

05HZL-01

- (d) The PPS (Progressive Power Steering) is vehicle speed sensing type power steering, which increases/decreases steering effort in accordance with vehicle speed.
 - The power steering ECU assy sends a control signal to the steering gear (PPS linear solenoid valve assy) based on a vehicle speed signal. This system enables obtainment of a heavy steering feeling when driving at high speeds.
 - (1) Power steering ECU assy
 The power steering ECU assy receives a vehicle speed signal from the combination meter.
 It then sends a signal to the PPS linear solenoid valve assy.
 - (2) PPS linear solenoid valve assy
 The PPS linear solenoid valve assy controls power steering fluid pressure by receiving a signal from the power steering ECU assy.