
CLEARANCE WARNING BUZZER NO.1 REPLACEMENT

9714H 0

HINT:

- •□ COMPONENTS:[\$EE[PAGE[71-1.
- •□ LOCATION: SEE PAGE 67-2.
- Installation[]s[]n[]the[]everse[order[of[]emoval.
- 1. REMOVE SWITCH BASE HOLE COVER SEE PAGE 71-6)
- 2. REMOVE[INSTRUMENT[PANEL[\$AFETY[PAD[\$UB-ASSY[NO.1[[SEE[PAGE[71-5]]



3. REMOVE CLEARANCE WARNING BUZZER NO.1

- (a) Disconnect the connector.
- (b) Disengage the clip and remove the clearance warning buzzer No.1.