
## CIGARETTE LIGHTER ASSY REPLACEMENT

0714NI 01

## HINT:

- •□ COMPONENTS: SEE PAGE 71-1.
- Installation is in the reverse order of removal.
- 1. REMOVE INSTRUMENT PANEL FINISH PANEL LOWER CENTER SEE PAGE 71-6)
- 2. REMOVE CONSOLE PANEL SUB-ASSY UPPER SEE PAGE 71-6)



## 3. REMOVE CIGARETTE LIGHTER ASSY

- (a) Rotate the socket cap counterclockwise to remove it.
- (b) Remove the cigarette lighter assy from the cigar–lighter hole bezel.

## 4. INSTALL CIGARETTE LIGHTER ASSY

- (a) Properly position the socket and ring at the cutout of the cigar–lighter hole bezel and insert them.
- (b) Rotate the socket cap clockwise from the backside.