REAR SEAT SWITCH SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

DI8M1-01

HINT:

This ECU is connected to the multiplex communication system. Therefore, be sure to check that there is no trouble in the multiplex communication system before performing the troubleshooting.

