
ELECTRONIC MODULATED AIR SUSPENSION SYSTEM PRECAUTION

SA0IK-0

HINT:

The Electronic Modulated Air Suspension is used in the LEXUS LS430.

Observe the following precautions strictly when performing operations on vehicles equipped with the Electronic Modulated Air Suspension.



1. TURN IGNITION SWITCH OFF WHEN JACKING UP VEHICLE

NOTICE:

If a vehicle is jacked up with the ignition switch ON (engine running), connect terminals Ts and CG of DLC3.

SST 09843-18040

2. REMOVE ALL ITEMS FROM UNDER VEHICLE BE-FORE LOWERING JACK

NOTICE:

When the jack is lowered, the vehicle is extremely low because the air in the pneumatic cylinder escapes.

3. ADJUST VEHICLE HEIGHT TO NORMAL CONDITION BEFORE MOVING VEHICLE

HINT:

When the ignition switch is turned ON (engine running), the vehicle height is automatically adjusted to normal condition.