
SA0KE-03



## **INSPECTION**

## **INSPECT SHOCK ABSORBER**

Compress and extend the shock absorber rod and check that there is no abnormal resistance or unusual operation sounds. If there is any abnormality, replace the shock absorber with a new one.

## **NOTICE:**

When discarding the shock absorber, see DISPOSAL on page \$A-95.