## **FUEL TANK AND LINE**

## **COMPONENTS**

## **CAUTION:**

- Always use new gaskets when replacing the fuel tank or component parts.
- Apply the proper torque to all parts tightened.

