## LEXUS NAVIGATION SYSTEM

## PRECAUTION

## **NOTICE:**

When disconnecting the negative (–) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01- <b>2</b> 0
Front Power Seat Control System	01-일0
Back Guide Monitor System	01-20

OECWE OF