DTC P1578 BRAKE SYSTEM MALFUNC	ΓΙΟΝ
--------------------------------	------

CIRCUIT DESCRIPTION

This DTC is output when the ABS with EBD & BA & TRAC & VSC system has a problem.

DTC No.	DTC Detection Condition	Trouble Area
P1578	ECM receives brake system error signal for 0.2 sec. or more while dynamic radar cruise control is in operation	ABS with EBD & BA & TRAC & VSC system

INSPECTION PROCEDURE

HINT:

This circuit uses CAN communication. Therefore, if there are any malfunctions in the communication circuit, one or more DTCs in the CAN communication system will be output.

CHECK ABS WITH EBD & BA & TRAC & VSC SYSTEM (See Pub. No. RM1049E, page 05-381)