RS–51

SUPPLEMENTAL RESTRAINT SYSTEM – CURTAIN SHIELD AIRBAG SENSOR ASSEMBLY

INSPECTION

RS0SJ–02

1. **Vehicles not involved in collision:**
INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI–1).

2. **Vehicle involved in collision and airbag is not deployed:**
INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI–1).

3. **Vehicle involved in collision and airbag is deployed:**

Replace the curtain shield airbag sensor assembly (See page RS–52).

LEXUS LS430 SUP   (RM875E)