DIAGNOSTIC TROUBLE CODE CHART

1. TRANSPONDER[KEY[ECU[DTC[CHART]

DTC[No. (See Page)	Detection Item	Trouble Area
B2780 (05-3043)	Push switch/key unlock warning switch malfunction	Unlock warning switch Wire harness Transponder key ECU assy
B2793 (05-3046)	Transponder chip malfunction	Key
B2794 (05-3047)	Unmatched encryption code	Key
B2795 (05–3048)	Unmatched key code	Key
B2796 (05–3049)	No communication in immobiliser system	KeyTransponder key amplifierWire harnessTransponder key ECU assy
B2797 (05–3052)	Communication malfunction No. 1	Key Wire harness Transponder key amplifier Transponder key ECU assy
B2798 (05-3049)	Communication malfunction No. 2	Key

2. **ECM DTC CHART**

NOTICE:

The DTCs for the immobilizer system are specified above. If the other codes are output, check the DTCs chart for the engine control system.

DTC No. (See Page)	Detection Item	Trouble Area
B2799 (05-3055)	Engine immobiliser system malfunction	Wire harness ECM

054CI-10