05B0G-05

| 1 | DTC | DOZOE | UNMATCHED KEY CODE |
|---|-----|-------|---------------------|
| ١ | DIC | D2/90 | UNIMATCHED RET CODE |

CIRCUIT DESCRIPTION

This DTC is output when a key with a key code that has not been registered in the ECU is inserted into the ignition key cylinder.

| DTC No. | DTC Detection Condition | Trouble Area |
|---------|--|--------------|
| B2795 | Key with unregistered key code is inserted | Smart key |

INSPECTION PROCEDURE

1 DELETE DTC AND INSERT ALL PRESENTLY AVAILABLE KEYS TO CHECK WHETHER ENGINE STARTS OR NOT

OK: Engine starts.

NG REPLACE KEY THAT CANNOT START ENGINE

OK

NO PROBLEM (BECAUSE OF KEY RE-REGISTRATION)