05I2Z-01

CUSTOMIZE PARAMETERS

HINT:

The following items can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that customization of the function(s) is possible.
- Be sure to record the current settings before customizing.
- When troubleshooting a function, first make sure that the function is not set to OFF.
 Meter ECU:

Display (Item)	Default	Contents	Setting
KEY REMND VOLUM	LARGE	Function that changes key reminder buzzer's volume	LARGE/MEDIUM/SMALL
KEY REMND SOUND	NORMAL	Function that changes key reminder buzzer's frequency	NORMAL/FAST/SLOW/0s