16 LS 430 (LHD) (Cont. next page) Power Source Moon Roof I17 IGNITION SW M 4 MOON ROOF CONTROL ECU J13(A), J14(B) JUNCTION CONNECTOR IG MPX1 UP DWN OPN CLS IG3 MPX2 UP DOWN OPN CLS C12 COMBINATION METER MULTI-DISPLAY CPU O 6 OVERHEAD J/B Right side of II Cowl side IK panel RH Cowl side IK panel RH Left side of instrument panel

16 LS 430 (LHD) (Cont' d)

