## DIAGNOSTIC TROUBLE CODE CHART

05HPG-01

 $If \verb|| []| rouble \verb|| code || s \verb|| displayed \verb|| during \verb|| the \verb|| DTC \verb|| check, \verb|| check \verb|| the \verb|| check || the check |$ 

DTC No. (See page)	Circuit Inspection	Trouble Area
B2231 (05-2238)	Front left side sensor malfunction	Ultrasonic sensor No.1 Wire harness Clearance warning ECU assy
B2232 (05-2240)	Front left sensor malfunction	Ultrasonic sensor No.1     Wire harness     Clearance warning ECU assy
B2233 (05-2242)	Front left center sensor malfunction	Ultrasonic sensor No.2 Wire harness Clearance warning ECU assy
B2234 (05-2244)	Front right center sensor malfunction	Ultrasonic sensor No.2     Wire harness     Clearance warning ECU assy
B2235 (05-2246)	Front right sensor malfunction	Ultrasonic sensor No.1     Wire harness     Clearance warning ECU assy
B2236 (05-2248)	Front right side sensor malfunction	Ultrasonic sensor No.1     Wire harness     Clearance warning ECU assy
B2237 (05-2250)	Rear left sensor malfunction	Ultrasonic sensor No.1     Wire harness     Clearance warning ECU assy
B2238 (05-2252)	Rear left center sensor malfunction	Ultrasonic sensor No.2     Wire harness     Clearance warning ECU assy
B2239 (05-2254)	Rear right center sensor malfunction	Ultrasonic sensor No.2     Wire harness     Clearance warning ECU assy
B2241 (05–2256)	Rear right sensor malfunction	Ultrasonic sensor No.1     Wire harness     Clearance warning ECU assy