INSPECTION

RS0SJ-01

Vehicles not involved in collision:
INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

2. Vehicle involved in collision and airbag is not deployed: INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do@diagnostic@system@heck@See@page@DI-484).

3. Vehicle involved in collision and airbag is deployed:

Replace the curtain shield airbag sensor assembly See page RS-84).