ON-VEHICLE INSPECTION

1. BASIC INSPECTION

- (a) With the ignition switch ON, the shift lever in the P position and the rear sunshade fully open, press the rear sunshade switch built into the front or rear control switch. Check that the rear sunshade closes fully.
- (b) After step (a), press the same switch again and check that the rear sunshade opens fully.
- (c) With the ignition switch ON, the shift lever in the P position and the rear sunshade fully closed, move the shift lever into the R (reverse) position. Check that the rear sunshade opens fully.
- (d) Turn the ignition switch OFF while the rear sunshade is moving up/down. Check that the rear sunshade stops moving.
- (e) After step (d), turn the ignition switch ON and press the rear sunshade switch built into the front or rear control switch. Check that the rear sunshade opens fully.

76151-01