③ : Engine Room No.3 R/B

Engine Compartment Left (LHD) [See Page 76]
Engine Compartment Right (RHD) [See Page 76]

