TORQUE SPECIFICATION

031UX-01

Part tightened		N·m	kgf⋅cm	ft·lbf
Fuel pipe sub-assy No. 2 x Fuel main tube	or use with SST	32	330	24
Intake air connector pipe x Air cleaner assy	for hose clamp	4.0	41	35 in.·lbf
Intake air connector pipe x Engine		5.0	51	44 in.·lbf
Pressuere gauge x Delivery pipe		39	400	29
Delivery pipe x Lower intake manifold		21	214	15.5
Vacuum switching valve x Intake manifold		18	184	13.2
V-Bank cover bracket No. 4 x Intake manifold		7.5	76.5	66 in.·lbf
V-Bank cover bracket No. 3 x Intake manifold		7.5	76.5	66 in.·lbf
V-Bank cover bracket No. 2 x Intake manifold		7.5	76.5	66 in.·lbf
V-Bank cover bracket No. 1 x Intake manifold		7.5	76.5	66 in.·lbf
Intake air pipe connector x Intake manifold	for hose clamp for bolt	4.0 5.0	41 51	35 in.·lbf 44 in.·lbf
V-Bank cover x V-Bank cover bracket		5.0	51	44 in.·lbf
Fuel tank vent tube set plate x Fuel tank		6.0	61	52 in.·lbf
Fuel sender gauge x Fuel tank		1.5	15	13 in.·lbf
Fuel tank x Body		39.2	400	29
Floor heat insulator x Fuel tank		5.4	55	47