BE21T-01

INSPECTION

INSPECT NEUTRAL START SWITCH CONTINUITY (See page DI-240)