POWER STEERING SYSTEM PRECAUTION

510GE 01

- 1. | HANDLING | PRECAUTIONS | FOR | STEERING | SYSTEM
- (a) Care must be aken when peplacing parts. Incorrect peplacement could affect the performance of the steering system and result in a driving hazard.
- 2. | HANDLING | PRECAUTIONS | FOR | \$RS | AIRBAG | \$YSTEM
- (a) The yehicle is equipped with \$RS \ Supplemental Restraint \ system \ such as \ airbags. If \ ervice \ peration \ is \ potential as \ in \ erious \ erious

NOTICE:

When the negative (-) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

| System Name | See page |
|---------------------------------|----------|
| Power Window Control System | 01–20 |
| Front Power Seat Control System | 01–20 |
| Back Guide Monitor System | 01–20 |