BO3ZW-01

# REASSEMBLY

### 1. INSTALL SEAT CUSHION COVER

(a) Install the seat cushion cover to the seat cushion pad with new hog rings.

### HINT:

When installing new hog ring, take care to prevent wrinkles as much as possible.

(b) Install the seat cushion frame with new hog rings to the seat cushion cover with pad.

### HINT:

When installing new hog ring, take care to prevent wrinkles as much as possible.

## 2. INSTALL SEATBACK COVER

(a) Install the seatback cover to the seatback pad with new hog rings.

### HINT:

When installing new hog ring, take care to prevent wrinkles as much as possible.

(b) Install the seatback frame with new hog rings to the seatback cover with pad.

### HINT:

When installing new hog ring, take care to prevent wrinkles as much as possible.

- (c) Install the 4 headrest supports.
- (d) Install the center headrest.

## 3. INSTALL CENTER ARMREST

- (a) Install the center armrest door with 2 screws.
- (b) Install the center armrest assembly with 2 nuts.

# 4. INSTALL BELT GUIDES

Install the 3 belt guides with 8 screws.