

11 LS 430 (LHD) (Cont' d)

Electronic Modulated Air Suspension H13 HEIGHT CONTROL SENSOR FRONT LH H14 HEIGHT CONTROL SENSOR FRONT RH H22 HEIGHT CONTROL SENSOR REAR A35 ACCELERATION SENSOR SHFL SGFL SHB SHG 7BE2 17BE2 5BE2 6BE2 22BE2 21BE2 C12 COMBINATION METER A23(A), A24(B), A25(C) AIR SUSPENSION ECU CPU S36 SUSPENSION CONTROL SUSPENSION CONTROL ACTUATOR FRONT LH SUSPENSION CONTROL ACTUATOR FRONT RH SUSPENSION CONTROL ACTUATOR REAR RH ACTUATOR REAR LH J27
JUNCTION
CONNECTOR

Rear floor
partition
panel RH Left side of instrument panel Cowl side panel RH Cowl side panel RH

1053

S

430 (EWD435F)