
## 8. Precaution for Pre-crash Safety System Operation

• When the millimeter wave radar sensor detects an object in front under the conditions described below, the distance control ECU may determine that a collision is unavoidable, and operate the pre-crash safety system. However, this is not abnormal.



• The millimeter wave radar sensor might not be able to detect the following objects as collision objects:

Objects that cannot be detected	Plastic items (Safety Cones, etc.), etc.
Objects that cannot be detected in a stable	People, Bicycles, Motorcycles, Trees, Animals, Snow Fence, etc.
manner	