
REAR SPEAKER ASSY REPLACEMENT

67140 01

HINT:

- •□ COMPONENTS: SEE PAGE 75-28.
- •□ LOCATION: [\$EE[PAGE[67-2.
- Installation is in the reverse order of removal.
- The procedure for the left side is the same as that for the right side. The procedure for right side is shown below.
- 1. REMOVE[\$IDE[TRIM[BOARD[COVER[FRONT[RH[[SEE[PAGE[75-32]]
- 2. REMOVE[\$IDE[REAR[CURTAIN[ASSY[RH[W/[REAR[CURTAIN[\$UB-ASSY)][SEE[PAGE[75-32]]
- 3. REMOVE[POWER[WINDOW[REGULATOR[\$WITCH[ASSY[REAR[]SEE[PAGE[75-32]]
- 4. REMOVE[REAR[DOOR[INSIDE[HANDLE[BEZEL[RH[]SEE[PAGE[75-32]]
- 5. REMOVE REAR DOOR TRIM BOARD SUB-ASSY RH (SEE PAGE 75-32)



6. REMOVE REAR SPEAKER ASSY

- (a) Disconnect the connector.
- (b) Remove the 3 screws and rear speaker assy.