HOW TO PROCEED WITH TROUBLESHOOTING

05I87–01

HINT:
- Use this procedure to troubleshoot the multiplex communication system.
- The intelligent tester II should be used in step 2.

1	**VEHICLE BROUGHT TO WORKSHOP**

2	**DTC CHECK (See page 05–3161)**

(a) Check for DTCs and note any codes that are output.
(b) Delete the DTC.
(c) Recheck for DTCs. Try to prompt the DTC by simulating the original activity that the DTC suggests.
    (1) If the DTC does not reoccur, proceed to A.
    (2) If the DTC reoccurs, proceed to B.

B ⟩ **Go to step 4**

A

3	**OVERALL ANALYSIS AND TROUBLESHOOTING**

(a) Terminals of ECU (see page 05–3141)

4	**ADJUST, REPAIR OR REPLACE**

5	**CONFIRMATION TEST**

END