
## 7614L-01

## HINT:


**REPLACEMENT** 

- The installation procedures are the removal procedures in reverse order.
- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.



## 1. REMOVE FRONT FENDER WHEEL OPENING MOULDING LH

(a) Remove the 4 screws and moulding.



## 2. REMOVE QUARTER PANEL WHEEL OPENING MOULDING LH

(a) Remove the 4 screws and moulding.