RS0NK–05

# INSPECTION

1. **Vehicle not involved in collision:**
   **INSPECT SUPPLEMENTAL RESTRAINT SYSTEM**

Do a diagnostic system check (See page DI–1).

2. **Vehicle involved in collision and airbag is not deployed:**
   **INSPECT SUPPLEMENTAL RESTRAINT SYSTEM**

Do a diagnostic system check (See page DI–1).

3. **Vehicle involved in collision and airbag is deployed:**
   **INSPECT SUPPLEMENTAL RESTRAINT SYSTEM**

Replace the side and curtain shield airbag sensor assembly (See page RS–44).