COMPONENTS

AT05K–02

Solenoid Modulator Valve
C–1 Accumulator Valve
Retainer
Plug
Check Valve
Retainer
Plug
Retainer
Plug
B–3 Control Valve
C–1 Orifice Control Valve
Retainer
Retainer
Plug
Sleeve
2–3 Shift Valve
Retainer
Plunger
Retainer
Plug
Secondary Regulator Valve
Strainer
Coast Brake Control Valve
Plate
Plunger
Strainer
Retainer
Retainer
Plunger
Retainer
Lock-up Relay Valve
Plug
Plug
Sleeve
Plug
4–5 Shift Valve
Plunger
C–0 Exhaust Valve
Sleeve
Retainer

N

D10761