**DISASSEMBLY** 

BR1L4-01

- 1. REMOVE PARKING BRAKE RELEASE CABLE
- 2. REMOVE PARKING BRAKE SWITCH

Remove the screw and parking brake switch from the parking brake control pedal assembly.

3. REMOVE PEDAL RETURN ABSORBER

Remove the 2 E-rings, pedal return absorber and bush.

4. REMOVE PEDAL PAD