
## **SYSTEM DIAGRAM**

The starting system rotates the starter motor according to the signals from the ignition switch.



190UP-01