
CENTER BODY PILLAR (CUT) REPLACEMENT

- 1. REMOVE CENTER BODY PILLAR
- (a) Cut and join the parts at the locations as shown below.
- (b) Shift the each cut and join locations of the outer panel, inner pillar and reinforcement.





2. INSTALL CENTER BODY PILLAR

HINT

Inspect the fitting of the front door and rear door, etc., before welding since this affects the appearance of the finish.

- (a) Cut the new parts for the rocker panel reinforcement at the locations as shown below.
- (b) Before temporarily installing the new parts, weld the rocker panel reinforcement, center body pillar reinforcement and center body inner pillar with standard points.
- (c) After welding the rocker panel reinforcement, center body pillar reinforcement and center body inner pillar to the vehicle install the outer pillar.
- (d) Temporarily install the new parts and measure each part in accordance with the body dimension diagram.





- 3. MEASURING THE OPENING PORTION DIMENSIONS (See page BP-88)
- 4. APPLYING SEALER TO THE INSIDE OF THE VEHICLE (See page PC-1)
- 5. APPLYING UNDER COATING (See page PC-7)
- 6. CHARGING THE POLYURETHANE FOAM (See page PC-9)
- 7. APPLYING ANTI-RUST AGENT
- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.