
FRONT LIGHT (BODY NO.5) CONTROL SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

DIRMG 0

HINT:

This ECU is connected to the multiplex communication system. Therefore, be sure to check that there is no troubles in the multiplex communication system before performing the troubleshooting.



LEXUS hand-held tester.