
REAR DOOR WINDOW FRAME MOULDING FRONT LH REPLACEMENT

7614G-02


HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- 1. REMOVE[REAR[DOOR[BELT[MOULDING[ASSY[LH[See]page]76-26]]
- 2. REMOVE REAR DOOR GLASS RUN LH
- (a) Remove the glass run from the rear door window frame.




3. REMOVE REAR DOOR WINDOW FRAME MOULDING FRONT LH

(a) Remove the 3 screws and moulding.



4. REMOVE REAR DOOR WEATHERSTRIP NO.2 LH

(a) Using a clip remover, remove the clip and weatherstrip.



5. REMOVE REAR DOOR WINDOW FRAME MOULDING UPPER LH


(a) Using a drill of less than ϕ 4 mm (0.16 in.), gently and perpendicularly place the drill tip onto the rivet and cut the rivet flanges.

HINT:

Wind tape around the drill blade so that the drill blade appears approx. 5 mm (0.20 in.) on the edge.

NOTICE:

- Be sure to gently place the drill perpendicular to the rivet, otherwise the rivet hole and the drill itself will be damaged.
- Be careful when performing this task, as the cut rivet is hot.
- (b) Do not prize the riveter. The riveter will be damaged and the mandrel will bend.
- (c) Using a clip remover, remove the clip and moulding from the door frame garnish.




6. INSTALL REAR DOOR WINDOW FRAME MOULDING UPPER LH

(a) Using an air riveter or hand riveter with nose piece, strike the 6 rivets into the door window frame to install the moulding to the door frame garnish.


NOTICE:

If the rivet is not positioned perpendicularly, it will bend the mandrel




NOTICE:

 Do not prize the riveter, because the riveter will be damaged and the mandrel will bend.



- Do not tilt the riveter when fastening the rivet to the item(s) as this will cause the rivet to be loose.
- Do not have any space between the rivet head and the item(s). The rivet head must be completely flat against the item(s).



Do not have any space between the items. Firmly hold together the two items while installing the rivet.