

INSTRUMENT PANEL COMPONENTS

BO3ZO-01





HINT:

Screw shapes and sizes are indicated in the table below. The codes ("A"-"M") correspond to those indicated on the previous pages.

								mm (in.)
Code	Shape							Size
A								L = 90 (3.54) Ø = 8 (0.31)
Code	Shape	Size	Code	Shape	Size	Code	Shape	Size
(B)		L = 20 (0.79) Ø = 8 (0.31)	0		L = 20 (0.79) Ø = 8 (0.31)	0		L = 25 (0.98) Ø = 6 (0.24)
(E)		L = 20 (0.79) Ø = 6 (0.24)	Ē		L = 16 (0.63) Ø = 6 (0.24)	G		L = 16 (0.63) Ø = 6 (0.24)
\oplus		L = 14 (0.55) Ø = 6 (0.24)	①	2 1000>	L = 14 (0.55) Ø = 5 (0.20)	J		ø = 8 (0.31)
8		ø = 6 (0.24)	0		Ø = 6 (0.24)	M	W. Carrent	ø = 6 (0.24)

P H16999