## 1 LS 430 (LHD) ELECTRICAL WIRING DIAGRAM Multiplex Communication System (Gateway ECU) Power Source 2 R-W I17 IGNITION SW J13 A JUNCTION CONNECTOR JUNCTION CONNECTOR 4 17 (DE) G 1 GATEWAY ECU MPL2 GTX+ SIL MPI1 MPI2 MPD1 MPD2 MPL1 8 (DG) See Multiplex Communication System (J/B ECU)<2-24> See Multiplex Communication System (J/B ECU)<2-24> 1 (4A) BATTERY Left side of Right side of IH shift lever