SS0C4-05

TORQUE SPECIFICATION

Part[<u>lig</u> htened	N·m	kgf⋅cm	ft·lbf	
Intermediate[shaft]x[]ransmission	79	805	58	
Propeller[shaft[x]Differential	79	805	58	
Front@enter@loor@rossmember@prace@@Body	13	130	9	
Rear@enter@loor@rossmember@brace@k@Body	13	130	9	
Heat[]nsulator[set[]bolt	5.4	55	48[jn.·lbf	
Propeller[shaft[heat[insulator[set[bolt	5.4	55	48[jn.·lbf	
Front[exhaust[pipe]x[Front[TWC	43	440	32	
Front@xhaustpipe[x[Center@xhaustpipe		See[page[EM-123		
Center support bearing x Body	37	375	27	
Propeller shaft adjusting nut	50 (69)	515 (700)	37 (51)	

^{():} For use without SST

LEXUS[]LS430[] (RM792E)